Owner's Manual

Lighting and Scene Programming

W-Bus Remote Control BC2-GSSR

Document Number 11W-001

NOV – 2008

Version 1.3

All Rights Reserved

INTRODUCTION

Thank you for purchasing your new BC2-GSSR W-Bus RF Remote Control. Your Remote will provide you with comfort and simplicity, and convenience for your life.

We hope that you take a few moments to become familiar with all of the features of this fine product by reviewing this manual. Please keep this manual on file for future reference.

DESCRIPTION

The BC2-GSSR W-Bus Remote Control is an RF Remote used to control the W-Bus Dimmer, Relay Switches, Curtains and Power Sockets. Also it can set Six different lighting scenes including ALL ON and ALL OFF.

It is friendly use , handheld remote , easy and fast to program.

OPERATION:

To take advantage of all the benefits and features offered by your remote, we recommend that you start by becoming familiar with its operation.

SMART-HDL®
Smart High Definition Living

W BUS

Programming

Your W-Bus BC2-GSSR remote may be programmed to control lighting channels, power socket, to Switch All light ON/OFF, and to set a scene.

1- Program Lighting Channel

To Program any lighting Channel Please Follow these instructions:

A- Keep pressing the Desired light button on the dimmer or relay switch until you hear single Beep Sound or until you see the LED ON in the E series Switch.

B- After you hear the beep sound or the LED ON , Press the desired Button in the remote control from 1 – 12.

C- After you press the desired button from 1-12 on the remote you will hear another single Beep sound or the LED will flash twice on the E series confirming that the program is done.

D- You can now test the programming, press the button that you had programmed , the light should switch on and off each time you press. If the channel is dimmer you can dim or brighten from the dimmer button on the remote.

2- Programming Scenes

The W-Bus BC2-GSSR Remote control can be programmed to 4 different scene, beside the All ON/ All Off , to program the scenes please follow these instructions:

First You have to Shake hands one time only between the Remote and all the switch that you need to include in the scene. To shake hands please do the following

A- keep Pressing any light button on the dimmer switch you want to include in scene until you hear single Beep Sound or until you see the LED ON in the E series Switch.

B- Press any scene button from scene 1 – scene 4 or All ON/All OFF, then you will hear the single beep sound again or you will see the LED flashing twice.

C- Repeat step A and step B for all the other desired switches inside the room that you want to include in your scene.

D- After you finish Shaking Hands all the desired switches with your remote control, now you are ready to program the scenes.

To program Scenes after the hand shaking do the following:

A- Keep Pressing the Learn Button for 4 seconds on the remote control until you see the remote led turning ON.

B- Switch OFF all the lights by pressing all switch Buttons that you want to include in the scene(even if the light was Off you have to switch it on then off again if you want to include it in the scene).

C- Make the desired mode you want in lighting switches, curtain, and power socket. For example dim some lights and Switch OFF others by pressing the switches buttons .

D- After you make your mode, press the LEARN+ SCENE desired Button together in the same time until the remote LED ON and off again.

E- Now you finish the scene programming , you can test by pressing the scene button on the remote control then you will see the lighting mode that you have programmed.

Note: to program another scene just repeat the step again (no need to shake hands again).

3- Deleting the programming

To delete the program just Keep pressing on the switch button that you want to delete its program until you hear the second Beep sound , or until you see the LED ON Flashing for the second time on E series switches.

4- Important Notes:

Note 1: when you delete the program on single button on the switch, the other buttons won't be effected , but all the scenes in the switch will be deleted.

Note 2: if you hear 2 times Beep sound on the switch, it means that the switch memory is full.

Note 3: if you hear 4 times Beep sound or you see 4 times LED Flash it mean that the programming is not done, so you have to re-program again per the instructions steps .

Note4: any programming of new scene will override the old scene.

For Customer Service or Technical Support Contact us at
PO Box 31255, Dubai UAE Tel: +971-4-3431323 Fax: +971-4-3431939
Email: support@smarthomeuae.com
Smart Home Control, Digitcom LLC