

QUICK REFERENCE GUIDE

PAGE	#, 7	"P" for PAGE. Speak into the phone receiver and your voice will be heard throughout the house over the ELAN speakers. (Pressing ##, automatically places a caller on hold; to return to the caller after the page, press any key.)
HOLD	#, 4	"H" for HOLD. Allows you to place caller on hold (with music), hang up, and take the call on another phone in the house.
PHONE-TO-PHONE Intercom	# , 7 , then press o	This allows you to talk with someone at another phone in the house after a page, without the conversation being heard over the ELAN speakers.
DOOR SPEAKER 1 DOOR SPEAKER 2	# 3 1	"D" for <i>DOOR</i> . Allows you to use a telephone to speak with someone over the door speaker.
DOOR LATCH 1 (OPTIONAL)	#, 3, 1, 0	Activates the door latch relay. The relay operates as long as you hold the
DOOR LATCH 2 (OPTIONAL)	$m{\#}$, $m{\Im}$, $m{\Im}$, $m{\Im}$,	
SYSTEM Bypass	#], []	The System Bypass allows you to use outside phone services that require use of the ## key.
MUSIC MUTE	#, 6	This command allows you to mute the music coming through your ELAN speakers for the duration of an incoming or outgoing call.
Note: If you have a caller on the line and you activate any of the ELAN features, the caller is automatically placed on hold.		
Off Hook Alert - If phone is left off hook, after two minutes a "double beep" is heard over all the speakers. Tele Mute - Music mutes for the duration of the telephone ring or door chime. FEATURES On Hold Alert - When you place a caller on hold using any telephone feature, after one minute of the phone being placed on hook the music will mute and a single "on hold" status tone will broadcast over the speakers.		
	#,1,(#,1,(#,1,(control automation functions that
RDER NO 7REE970	#,1,	the command for quick reference.